UNCLASSIFIED

AD NUMBER AD323745 CLASSIFICATION CHANGES TO: unclassified FROM: confidential LIMITATION CHANGES

TO:

Approved for public release; distribution is unlimited.

FROM:

Controlling Organization: British Embassy, 3100 Massachusetts Avenue, NW, Washington, DC 20008.

AUTHORITY

DSTL, DSIR 23/28633, 11 Dec 2008; DSTL, DSIR 23/28633, 11 Dec 2008

R.P.E. TECH. NOTE No.190

Decl OADR

12

AD 323745

PROPULSION ESTABLISHMENT (9.18.)
WESTCOTT, BUCKINGHAMSHIRE

3/ R.P.E. TECHNICAL NOTE No: 190

4/ SOME ASPECTS OF THE DESIGN OF STAR-CENTRE SOLID PROPELLENT ROCKET CHARGES

by

K. E. SILMAN

EXCLUDED FROM AUTOMATIC REGRADING DOD DIR 5200.10 DOES NOT APPLY

6/ AUGUST, 1960

10, OTIA 10717

PICATINNY ARSENAL
TECHNICAL INFORMATION SECTION



MINISTRY OF AVIATION

THIS DOCUMENT IS THE PROPERTY OF H.M. GOVERNMENT AND ATTENTION IS CALLED TO THE PENALTIES ATTACHING TO ANY INFRINGEMENT OF THE OFFICIAL SECRETS ACT, 1911-1939

It is intended for the use of the recipient only, and for communication to such officers under him as may require to be acquainted with its contents in the course of their duties. The officers exercising this power of communication are responsible that such information is imported with due caution and reserve. Any person other than the authorised holder, upon obtaining possession of this document, by finding or otherwise, should forward it, together with his name and address, in a closed envelope to:-

THE SECRETARY, MINISTRY OF AVIATION, LONDON, W.C.2

Letter postage need not be prepaid, other postage will be refunded. All persons are hereby warned that the unauthorised retention or destruction of this document is an offence against the Official Secrets. Act

CONFIDENTIAL

rug # 15766

20080730 177

DIV 90

(1)

SUBJECTS

1. Rochet propellants - Design I S'Iman, K. E.

2. Propellent grains - Design II Little: Star-contribution pupillant grains - Design III

3.

1. Rochet propellants - Design III Little: Star-contribution pupillant grains - Design III

3.

1. V Project No.

V Project No.

VI Contract No.

3 copies

U.D.C. No. 621.455-846

Technical Note No. 190
August, 1960

ROCKET PROPULSION ESTABLISHMENT

WESTCOTT

SOME ASPECTS OF THE DESIGN OF STAR-CENTRE SOLID PROPELLENT ROCKET CHARGES

by

K. E. Silman

SUMMARY

A mathematical treatment of a family of suitable designs is presented in the form of charts showing the inter-relation of density of loading, sliver fraction and web thickness.

CONFIDENTIAL

Technical Note No. 190

LIST OF CONTENTS

		Page
1	INTRODUCTION	3
2	EXPLANATION OF NOMENCLATURE	3
3	THE DESIGN OF STAR-CENTRE CHARGES	4
	3.1 Typical charge	4
	3.2 The effect of the number of lobes	4
4	DESIGN CHARTS	5
	 4.1 General 4.2 Six-pointed star-centre designs with values of a other than π 	5 5
	4.3 Approximate equations for six-pointed star-centre designs	6
REFER	RENCES	7
ADVAN	ICE DISTRIBUTION	8
TABLE	ES I AND II	9
APPEN	IDIX	10 -14
ILLUS	TRATIONS Fig. 1-11	-
DETAC	CHABLE ABSTRACT CARDS	•
	LIST OF TABLES	
Table		
I	Conditions for neutral burning	9
II	Maximum density of loading for neutral burning and $P = 2\pi R$	9
	APPENDIX	
Geome	etry of star-oentre charge designs	10 - 14
	LIST OF ILLUSTRATIONS	
		Figure
Typic	cal star-oentre charge design	1
-	ent of star-centre charge showing notation	2
Neut	ral burning star-centre design, N = 5, P = 2πR	3
	ral burning star-centre design, N = 6, P = 2πR	4
	ral burning star-centre design, N = 7, P = 2πR	5
Neut	ral burning star-centre design, N = 8, P = 2πR	6
Vari	ation of sliver with web thickness	7
Neut	ral burning 6-point star-centre design, P = 2aR	8
	ral burning 6-point star-centre design, P = 2aR	9
	ible end of burning conditions	10
Neut to	ral burning star-centre design, web and star-centre burn out gether, i.e. $P_A = P_w = P_c = 2a*R$, variation of $a*$ with N and ϕ/β	11

1 INTRODUCTION

Designing solid propellent charges is an art. If this is recognised then the methods now presented will be accepted in their right perspective as another attempt to formulate a rational basis for designing charges in which burning occurs at approximately constant pressure on the surface of a central conduit of star form.

The condition of constant burning pressure demands constant surface area of burning except for the initial period in which erosive burning may occur.

Already several reports have been written on the mathematical approach to star-centre charge design. Two of the earliest reports known to the writer are those of references 1 and 2, whilst later reports giving more arithmetical results are listed as references 3, 4 and 5. The treatment presented in this paper is new and the results are in a convenient form for assessment work.

2 EXPLANATION OF NOMENCLATURE

A typical form of star-centre charge is shown in Fig.1 and some of the defining quantities are shown in Fig.2. These, and others not capable of pictorial presentation, are given below.

The mathematical exercise is feasible only if the surface area of burning is confined to the conduit; that this surface is the product of the axial length of the conduit and the perimeter of the conduit in the plane normal to the axis of the conduit, and that the axial length is constant. Burning at constant pressure, now defined as "neutral burning", therefore implies that the perimeter of the conduit shall be constant.

List of Symbols

- P' Imaginary initial perimeter (see Fig.2)
- P, Actual initial perimeter
- P Any intermediate perimeter
- P. Perimeter at instant of web burn out
- R Outermost radius of charge (inner radius of motor case if the charge is case-bonded)
- r, Initial radius of fillet at junction of lobe and web (see Fig.1)
- r₂ Initial radius of lobe tips
- N Number of lobes
- w' Web thickness corresponding to imaginary initial perimeter
- w Web thickness corresponding to actual initial perimeter
- a Constant, where P = 2aR
- a* Value of a for simultaneous burn out of web and lobe
- b' The distance measured normal to the lobe face from the imaginary initial junction of the lobe face and the web to the centre line of the lobe (see Fig. 2)

Technical Note No. 190

- b Specified as b' r₁ (see Fig.2)
- β Segment angle (including semi-web and semi-lobe = π/N
- φ Design angle (when 2φ includes one imaginary web portion)
- α Design angle (see Fig. 2)
- Angle subtended by circular arc of a semi-sliver at the imaginary initial junction of lobe and web, at instant of web burn-out, for the case of prior lobe burn through (see Fig. 10a)
- ε Sliver fraction, i.e. Total cross-sectional area of slivers at web burn-out
 Initial cross-sectional area of charge
- Density of loading, i.e. Initial cross-sectional area of charge πR^2
- λ Density of loading for the imaginary initial perimeter
- 3 THE DESIGN OF STAR-CENTRE CHARGES

3.1 Typical charge

The cross-section of a typical star-centre charge is shown in Fig. 1, and it will be seen that there are no sharp corners. The apices of the lobes are rounded to reduce the initial burning perimeter and so reduce or eliminate the high initial pressure peak that would otherwise occur (an alternative treatment is suggested in reference 2). Fillets are provided at the junctions of the lobes and the webs to eliminate stress concentrations, which might lead to cracking of the charge during storage or firing.

A single charge segment is shown in Fig. 2, together with generating lines and details of angles. The geometry of this type of charge design is investigated in the Appendix.

3.2 The effect of the number of lobes

The final perimeter of the conduit at web burn-out is likely to be only slightly greater than $2\pi R$, so the first designs investigated were those giving neutral burning for the greater part of the effective burning time, and having a conduit perimeter of $2\pi R$. The condition for neutral burning is derived in the Appendix and it will be seen that this is satisfied by a certain value of the angle $(\alpha + \phi)$; this has been found for values of N from 2 to 16 and the results are given in Table I. For N less than or equal to 5, Table I shows that the lobe side is re-entrant for neutral burning, that is $(\alpha + \phi)$ is greater than 90 degrees, which means that for small values of ϕ , and sharp corners, an impossible design could result with the apices overlapping. The maximum density of loading, the ratio w/R, and the sliver fraction, have been calculated for the above condition $(P = 2\pi R)$, and are tabulated in Table II for N from 2 to 16, for designs having sharp corners. These designs, for values of N of 5 or less, have the lobe apices just meeting; the effect of rounding off the corners is dealt with in the Appendix.

It will be seen that the maximum density of loading occurs at N equal to 6, with only a slightly lower value at N equal to 5. This is not really surprising, since consideration of the angle $(\alpha + \phi)$ would show that a maximum density of loading equal to 1.0 would be achieved when $(\alpha + \phi)$ is equal to 90 degrees; for neutral burning, this would occur with a value of N of 5.55 which is not possible.

4 DESIGN CHARTS

4.1 General

Detail charts have been produced for star-centre designs, to have neutral burning characteristics ($P = 2\pi R$), for values of N of 5, 6, 7 and 8, and these are shown in Fig. 3, 4, 5 and 6. Basically, the density of loading is plotted against web thickness/charge radius (w/R) and the radius at the outer star point/charge radius (r_1/R). On this are superimposed lines of constant sliver area/motor area ($\lambda \epsilon$), which occur as straight lines, and lines of constant proportions of neutral burning (b/w). Also shown in a small picture is the ratio of the final perimeter at web burn-out to the normal perimeter ($P_1/2\pi R$) plotted against the design angle ϕ ; the value of ϕ can be found from the main chart, since the values are shown on the boundaries and a line of constant ϕ would appear as a straight line parallel to a line of constant $\lambda \epsilon$.

In Fig. 3, for a 5-point star design, it will be seen that the upper part of the diagram has been cut off at a density of loading of about 0.95. This is due to the fundamental requirement that the lobe apices cannot overlap.

The effect of rounding the lobe apex to reduce the initial perimeter will only reduce the density of loading λ , and will not affect the values of $\lambda \epsilon$, or $P_w/2\pi R$. The proportion of neutral burning will be reduced by r_2/w at the beginning, when the burning is progressive.

Since the lines of constant sliver/motor area ($\lambda \epsilon$) are not evenly spaced across the diagrams, curves of sliver/motor area ($\lambda \epsilon$) against the parameter (w + r_1)/R are shown in Fig. 7 for values of N of 5, 6, 7 and 8.

For given web thickness/charge radius (w/R) and density of loading λ , the sliver/motor area (λ s) is very nearly independent of the number of star points. The proportion of neutral burning (b/w) reduces, and the final perimeter increases, with increase in the number of star points. Also, for a given web thickness/charge radius (w/R), the range of density of loading that can be considered is reduced as N is increased, the maximum being reduced and the minimum increased. From these points of view, it is suggested that 5 or 6 pointed star-centre designs are likely to be the most useful.

4.2 Six-pointed star-centre designs with values of a other than π

It was considered that some investigation should be made into the effect of varying the constant a. In Fig. 8, the density of loading with sharp corners ($\lambda^{!}$) is shown as a function of web thickness/charge radius and the constant a. Also shown are lines of constant sliver area/motor area and lines of constant final perimeter/normal perimeter ($P_{W}/2aR$). The value of the design angle ϕ is shown in Fig. 9 against web thickness/charge radius and the constant a. With sharp corners, lines of constant proportions of neutral burning ($b^{!}/w^{!}$) are also shown.

As is shown in the Appendix, for a greater than a*, the web will burn out before the star side and there will be neutral burning until web burn-out. In the present case a* is slightly less than 3.4.

Let us now consider the effects of varying the value of a. Suppose we start at a large value of a. At constant density of loading, as a is reduced we have the following effects:

- (i) the sliver fraction is reduced, since λ is constant,
- (ii) web thickness/charge radius is increased,
- (iii) there is no change in the final perimeter/normal perimeter $(P_{\rm w}/2aR)$ until a = a*, but as a is further reduced, this ratio increases.
- (iv) as an alternative to (iii) the proportion of neutral burning (b'/w') reduces as a is reduced below a*.

Due to the method of filling rocket motor tubes with plastic propellent some increase in perimeter can be permitted if the burning surface is to be kept constant, since the initial length of the charge is greater than the final length, as the propellent is pressed into the head and rear domes as well as the parallel portion of the tube. Since the reduction in length is unlikely to exceed 10%, unless the charge length/diameter is low, the maximum value of final perimeter/normal perimeter would be 1.10. Also, there do not appear to be any very valid reasons for having a greater than a*, so that the reasonable range of a is from 2.9 to 3.4.

4.3 Approximate equations for six-pointed star-centre designs

For project assessment work, it was considered that it would be useful to have some approximate equations relating density of loading, web thickness, sliver, etc. From the earlier discussion, several reasons have been given for using 5 or 6-pointed star centres, and for this case the 6-pointed star was used, with a perimeter of $2\pi R$.

Assuming that a density of loading less than 0.6 would not be of interest, the following equations were obtained, and the R.M.S. error is also given:

R.M.S. error
0.004.722
0.004791
0.000069
0.003530
R.M.S. error
0.000752
0.000766
0.000014
0.000191

Now, as shown in the Appendix, the actual density of loading is given by:

Technical Note No. 190

and
$$\lambda = \lambda' - (2r_1/R) - (r_2/R)^2$$

$$(w'/R) = (w/R) + (r_1/R)$$

$$(r_2/R)^2 = (1 - P_1/P)^2$$

e.g. it may be found that for a given propellent under certain conditions, a value of P./P of 0.9 will be sufficient to remove an initial pressure peak and a value of 0.005 for r./R will be adequate to safeguard against charge cracking. Then

$$\lambda = \lambda^{\dagger} - 0.02$$

$$(w/R) = (w^{1}/R) - 0.005$$

and

$$\lambda - \lambda \epsilon = (\lambda^{\dagger} - \lambda \epsilon) - 0.02$$
.

It will be realised that $(\lambda - \lambda \epsilon)$ represents the charge area burnt away at burn-out, and the equations given represent extremely good approximations to this.

LIST OF REFERENCES

No.	Author	Title, etc.
1	Jones, C.W.	A systematic method for the evaluation of design data for rocket charges to meet specific requirements P.D.E. Report No. 1945/14, February 1945
2		Notes on rocket charge design: 1 The geometrical characteristics of charges with star centre and burning inhibited on the outer surface P.D.E. Note No. 1944/25, December 1944.
3		Quarterly progress report on interior ballistics Rohm & Haas Company No. P-55-15, August 10th, 1955
4	Piasecki, L. Robillard, G.	Generalised design equations for an internal- burning star-configuration solid propellent charge and method of calculating pressure-time and thrust-time relationship J.P.L./C.I.T. Memo. 20-135, September 18th, 1956
5	Epstein, L.I.	The design of cylindrical propellant grains Jet Propulsion, 26(1956), No.9, 757

CONFIDENTIAL

Technical Note No. 190

ATTACHED:

Tables I and II
Appendix
Drgs. No. RP 2768 - 2777
Detachable abstract cards

ADVANCE DISTRIBUTION

Ministry of Aviation:-		
DG/GW	AD/GW(P&W)	
DG/BM	AD/MXRD(X)	
DG(Eng)	D/ERDE	3
D Eng 1	RAE Farnborough	5
D/GW (Tech)	GW(A) 1(b)	70
DMXPD	TIL 1(b)	100

TABLE I
Conditions for neutral burning

			medi	the open
N	β		$\alpha + \phi$	
1	Radian	Degree, minute	Radian	Degree, minute
2	1.57079633	90°	2.79838605	160° 20.143°
3	1.04719755	60°	2.18957409	125° 27.2011
4	0.78539816	45°	1.86372955	1060 47.0301
5	0.62831853	36°	1.65580688	94° 52.2451
6	0.52359878	30°	1.50921626	86° 28.3031
7	0 . 44879895	25° 42.857'	1.39901178	80° 9.448°
8	0.39269908	22° 30°	1.31237148	75° 11.6011
9	0.34906585	20°	1.24197868	71° 9.608'
10	0 <mark>.314</mark> 15 <mark>9</mark> 27	18°	1.18332827	67° 47.9831
12	0.26179939	15°	1.09042934	62° 28.620'
14	0.224.39948	12° 51.429'	1.01940817	58° 24.1.67°
16	0 <u>. 19634</u> 954	110 151	0.96279471	55° 9.844°

N	w'/R	λί	λε	Pw'/2πR
2	0.294.84.5	0.611400	0.020985	1.021495
3	0.353094	0.752720	0.047644	1.022683
4	0.392545	0.862372	0.075791	1.029316
5	0.420910	0.954628	0.111233	1.029335
6	0.1,21582	0.964403	0.119542	1.030276
7	0.398500	0.897179	0.098275	1.032533
8	0.378057	0.841057	0.082943	1.033645
9	0.359935	0.793307	0.071407	1.034093
10	0.343798	0.752057	0.062442	1.034144
12	0,316331	0.684073	0.049475	1.033608
12+	0.293810	0.63001.8	0.01,0608	1.032685
16	0.274970	0.585842	0.034205	1.031634

Technical Note No. 190

APPENDIX

GEOMETRY OF STAR-CENTRE CHARGE DESIGNS

Some consideration has already been given 2,3,4 to this type of design but with various limitations, such as $\phi=0$, $r_2=0$, or $r_1/R=0.06$. To simplify the equations we will assume initially that $r_2=0$ and use winstead of $(w+r_1)$.

The initial perimeter P' is given by

$$\frac{P!}{2N} = (R - w!) \phi + \frac{(R - w!) \sin (\beta - \phi)}{\cos (\alpha + \phi - \beta)}$$
(1)

and after a distance x has burnt the perimeter Px is given by

$$\frac{P_{x}}{2N} = (R - w^{1} + x) \phi + x\alpha + \frac{(R - w^{1}) \sin (\beta - \phi)}{\cos (\alpha + \phi - \beta)} - x \tan (\alpha + \phi - \beta)$$
 (2)

provided that the star side has not burnt out.

Until the star side or the web burns out, whichever occurs first, we have, by differentiating (2)

$$\frac{1}{2N} \left(\frac{d^{P}x}{dx} \right) = \alpha + \phi - \tan (\alpha + \phi - \beta). \tag{3}$$

Density of loading

The cross-sectional area of the charge $(\pi R^2 \lambda^i)$ can be shown to be

$$N\left[R^{2} \beta - (R-w^{\dagger})^{2} \phi - \frac{(R-w^{\dagger})^{2} \sin (\beta - \phi) \cos \alpha}{\cos (\alpha + \phi - \beta)}\right]$$

or

$$\lambda^{\dagger} = 1 - \left(1 - \frac{\mathbf{w}^{\dagger}}{\mathbf{R}}\right)^{2} \frac{\phi}{\beta} - \left(1 - \frac{\mathbf{w}^{\dagger}}{\mathbf{R}}\right)^{2} \frac{\sin(\beta - \phi)\cos\alpha}{\beta\cos(\alpha + \phi - \beta)}. \tag{4}$$

Sliver area

The portion of the charge referred to as sliver is shown in Fig. 10a and Fig. 10b, where it will be seen that two equations are required, according to whether the star side burns out before the web or the converse. If the side has burnt out first as in Fig. 10a

Sliver area/N =
$$R^2(\beta - \phi) - (w^i)^2 \alpha^i - w^i(R - w^i) \sin \alpha^i$$

where

$$\alpha^{\dagger} = (\beta - \phi) + \sin^{-1} \{(R - w^{\dagger}) \sin (\beta - \phi) w^{\dagger}\},$$

or sliver area/motor area,

$$\lambda \varepsilon = 1 - \frac{\phi}{\beta} - \left(\frac{\mathbf{w}^{\dagger}}{R}\right)^{2} \frac{\alpha^{\dagger}}{\beta} - \left(\frac{\mathbf{w}^{\dagger}}{R}\right) \left(1 - \frac{\mathbf{w}^{\dagger}}{R}\right) \frac{\sin \alpha^{\dagger}}{\beta}. \tag{5}$$

For the case shown in Fig. 10b, where the web burns out before the starside, it can be shown that

Sliver area/N =
$$R^2(\beta - \phi) + (w^i)^2 \{ \tan (\alpha + \phi - \beta) - \alpha \}$$

$$- \frac{(R - w^i) \sin (\beta - \phi)}{\cos (\alpha + \phi - \beta)} \{ (R - w^i) \cos \alpha + 2 w^i \},$$

or sliver area/motor area,

$$\lambda \varepsilon = 1 - \frac{\phi}{\beta} + \left(\frac{w^{i}}{R}\right)^{2} \frac{\tan (\alpha + \phi - \beta) - \alpha}{\beta}$$

$$- \left\{ \left(1 - \frac{w^{i}}{R}\right) \frac{\sin (\beta - \phi)}{\beta \cos (\alpha + \phi - \beta)} \right\} \left\{ \left(1 - \frac{w^{i}}{R}\right) \cos \alpha + \frac{2w^{i}}{R} \right\}. \quad (6)$$

Effect of rounding outer star point i.e. r₁ = 0

Decrease in density of loading = - $\Delta\lambda_1$

$$= \frac{1}{\pi R^2} \int_{0}^{r_1} P_x dx$$

$$= \frac{2}{\beta} \left(\frac{r_1}{R} \right) \left(1 - \frac{w^t}{R} \right) \left(\phi + \frac{\sin (\beta - \phi)}{\cos (\alpha + \phi - \beta)} \right) + \left(\frac{r_1}{R} \right)^2 \frac{(\alpha + \phi) - \tan (\alpha - \phi - \beta)}{\beta}. \quad (7)$$

Effect of rounding lobe apex i.e. r2 + 0

Reduction in initial perimeter

$$= 2N r_2 \left\{ \tan \left(\alpha + \phi - \beta \right) - \left(\alpha + \phi - \beta \right) \right\}. \tag{8}$$

Reduction in density of loading = $-\Delta\lambda_2$

$$= \left(\frac{N}{\pi}\right) \left(\frac{r_2}{R}\right)^2 \left\{ \tan \left(\alpha + \phi - \beta\right) - \left(\alpha + \phi - \beta\right) \right\}. \tag{9}$$

Final perimeter

If the star side burns out first, the final perimeter at web burn-out, $P_{\rm w}$, is given by

$$P_{w}/2N = R(\beta - \phi) + w^{\dagger}\alpha^{\dagger}. \qquad (10)$$

If the star side has not burnt out

$$\frac{P}{2N} = R\phi + w^{\dagger}\alpha + \frac{(R - w^{\dagger}) \sin (\beta - \phi)}{\cos (\alpha + \phi - \beta)} - w^{\dagger} \tan (\alpha + \phi - \beta). \tag{11}$$

Neutral burning

In this case, it is necessary to make $dP_x/dx = 0$, or

$$(\alpha + \phi) = \tan (\alpha + \phi - \beta)$$
 (12)

where

$$\beta = \pi/N$$

Equation (12) has been solved by iteration for N=2, 3, 4 ... 9, 10, 12, 14, 16, and the values of $(\alpha + \phi)$ are given in Table I in both radian and circular measure.

For a given value of N, increasing the value of $(\alpha + \phi)$ from that for neutral burning will make dP_X/dx negative, and reducing the value of $(\alpha + \phi)$ will give progressive burning.

Initial perimeter = 2aR

Substituting this value in equation (1) we obtain

$$\left(1 - \frac{\mathbf{w}^{\dagger}}{\mathbf{R}}\right) = \left(\frac{\mathbf{a}}{\mathbf{N}}\right) \left\{\phi + \frac{\sin(\beta - \phi)}{\cos(\alpha + \phi - \beta)}\right\}. \tag{13}$$

Now $(\alpha + \phi)$ and β are constants for given N, and equation (13) enables the value of $(1 - w^{1}/R)$ to be found for various values of ϕ .

Effect of rounding outer star points and lobe apices

In this case, when r_1 is small, P_x is constant at 2aR. Hence equations (7) and (9) become

$$-\Delta \lambda_1 = 2a r_1/\pi R \tag{7a}$$

$$-\Delta \lambda_2 = (r_2/R)^2$$

$$= \left(\frac{a}{\pi}\right)^2 \left(1 - \frac{P_i}{P}\right)^2. \tag{9a}$$

Density of loading, λ

This quantity is found from equation (4) using the value of w^{4}/R from equation (13), and equations (7a) and (9a).

Sliver fraction

The value of sliver fraction is obtained by using equation (5) or (6) together with the density of loading found above. The value of a will determine whether equation (5) or equation (6) should be used. The star side will burn out at the same time as the web, if the length b' in Fig. 2 is equal to w'. That is, if

$$(R - w') \sin (\beta - \phi) = w' \sin (\alpha + \phi - \beta)$$
,

and this will be satisfied when

$$a = a^* = N(\alpha + \phi) \frac{\sin(\beta - \phi) + \phi\cos(\alpha + \phi - \beta)}{\sin(\beta - \phi) + \sin(\alpha + \phi - \beta)}.$$
 (14)

The value of a^* has been evaluated for N between 2 and 16 and ϕ between 0 and β and the results are shown in Fig. 11. Also shown in this figure is a line for $\alpha = 90$ deg. which occurs when the star points just meet for r_1 and $r_2 = zero$. If a is less than a^* , the side will burn out before the web, and if a is greater than a^* , the web will burn out first.

Proportion of neutral burning

This is the ratio (b/w) or $(b! - r_1)/(w! - r_1)$.

Now

$$b' = \frac{(R - w') \sin (\beta - \phi)}{\sin (\alpha + \phi - \beta)},$$

and, therefore,

$$\frac{b}{w} = \frac{(R - w^{\dagger}) \sin (\beta - \phi) - r_1 \sin (\alpha + \phi - \beta)}{(w^{\dagger} - r_1) \sin (\alpha + \phi - \beta)}.$$
 (15)




FIG. 2 SEGMENT OF STAR-CENTRE CHARGE DESIGN SHOWING NOTATION




FIG. 3 NEUTRAL BURNING STAR-CENTRE CHARGE DESIGN N = 5, P = 278




FIG. 4 NEUTRAL BURNING STAR-CENTRE CHARGE DESIGN N= 6, P=2MR




FIG. 5 NEUTRAL BURNING STAR-CENTRE CHARGE DESIGN N=7, P = 2 MR




FIG. 6 NEUTRAL BURNING STAR-CENTRE CHARGE DESIGN N=8, P= 2 TR





FIG. 7 VARIATION OF SLIVER WITH WEB THICKNESS









FIG. 9 NEUTRAL BURNING 6 - POINT STAR-CENTRE CHARGE DESIGN P. 2 0R






FIG. 10 POSSIBLE END OF BURNING CONDITIONS




FIG. II NEUTRAL BURNING STAR-CENTRE CHARGE DESIGN, WEB AND LOBE BURN. OUT TOGETHER i.e. $P_X = P_W^1 = P_0 = 2 d^2R$, variation of a * With N AND ϕ / β



Intermenten Centre Knowledge Services [dstl] Porton Down. Salashury Wills $SP \neq UJO$ 22060-6218 Tal. 01980-613753 Fix 01989-613970

Defense Technical Information Center (DTIC) 8725 John J. Kingman Road, Suit 0944 Fort Belvoir, VA 22060-6218 U.S.A.

AD#: AD 323745

Date of Search: 11 December 2008

Record Summary: DSIR 23/28633

Title: Some aspects of the design of star centre solid propellant rocket charges (RPE TN Availability Open Document, Open Description, Normal Closure before FOI Act: 30 years

Former reference (Department) ARC 22796 Held by The National Archives, Kew

This document is now available at the National Archives, Kew, Surrey, United Kingdom.

DTIC has checked the National Archives Catalogue website (http://www.nationalarchives.gov.uk) and found the document is available and releasable to the public.

Access to UK public records is governed by statute, namely the Public Records Act, 1958, and the Public Records Act, 1967. The document has been released under the 30 year rule. (The vast majority of records selected for permanent preservation are made available to the public when they are 30 years old. This is commonly referred to as the 30 year rule and was established by the Public Records Act of 1967).

This document may be treated as **UNLIMITED**.